



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

FLUSH PULL

FOR USE ON SLIDING DOORS. FEATURES
IVES' EXCLUSIVE BUILT-IN PRONGS —
NO SCREWS OR BRADS NEEDED.

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Hammer, punch, drill
and 2 1/8" spade bit.

1. Position, mark and bore hole 2 1/8" wide
× 7/16" deep.
2. Insert pull and push out prongs as
illustrated.

