



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Drill, $\frac{7}{64}$ " drill bit for pilot holes, chisel, Phillips screwdriver, and pencil.

1. Place bolt in desired horizontal or vertical position flush with edge of door. Slide bolt to left, exposing right screw hole, drill and secure.
2. Slide bolt to right, exposing left hole, drill and secure.
3. To install universal strike - (Illustration A) align with bolt, outline, mortise, and secure.
4. To install mortise strike - (Illustration B) align with bolt and outline. Using drill and chisel mortise to depth of $\frac{7}{8}$ ". Secure with screws.

