



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

## INSTALLATION INSTRUCTIONS

**TOOLS REQUIRED:** Drill,  $\frac{1}{16}$ " drill bit, Phillips screwdriver, awl or pencil.

1. Position plate (A) approximately 52" from bottom of door. Mark, drill pilot holes, and secure.
2. Position chain holder (B) at same height as plate. Before securing chain holder, make sure distance between chain holder and plate is no more than  $\frac{1}{2}$ ". Mark, drill pilot holes and secure.

