



**TRADEMARK
HARDWARE**

WORLD OF QUALITY HARDWARE

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED: Phillips screwdriver, awl or pencil.

1. Locate stop in the center of baseboard and approximately 1" from door edge and mark.
2. Secure base with screw provided.
3. Attach flexible spring to base.

