



**TRADEMARK  
HARDWARE**

WORLD OF QUALITY HARDWARE

## **INSTALLATION INSTRUCTIONS**

**TOOLS REQUIRED:** Drill, 1/8" drill bit, Phillips screwdriver, awl or pencil.

1. Position casement adjuster on window sill flush to bottom rail, leaving ball end or rod a minimum 1/2" from window frame. (See illustration 1)
2. Mark screw holes in mounting piece (A) and base (C).
3. Remove adjuster and drill pilot holes. Pull rod (B) inward (90°) and secure mounting piece (A) to window and base (C) to sill.

**NOTE:** To keep in desired open position, tighten knob.

**For other applications see illustrations 2, 3, 4 and 5.**

