



*441F
*446F

*448F
*449F

*Lever handle design
prefixes "AU", "MO", or "PB"

Notes:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Prepare mounting holes when installing trim.
6. Provide adequate structural support to maintain door integrity during operation.
7. ANSI/BHMA A156.115, which cover hardware preparations for steel doors and steel frames, and A156.115-W, which cover hardware preparations for wood doors with wood or steel frames.
8. Dimensions given about a centerline are symmetrical.

441F, 446F, 448F and 449F Trim
With 2100(F), 6100(F), 6170(F) or 1800(F) Series
Rim and Vertical Rod Exit Devices
Wood Door Preparation



1-800-438-1951
www.yalelocks.com

TEMPLATE NUMBER

7400-1441

DATE

06-15