

**Notes:**

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Prepare mounting holes when installing trim.
6. Provide adequate structural support to maintain door integrity during operation.

214F Trim
For 2100(F) Series Rim and Vertical Rod Exit Devices
Wood Door Preparation

Yale®

Yale Commercial Locks and Hardware

www.yalecommercial.com

TEMPLATE NUMBER

7400-1214

DATE

8-99